

HOW TO REPLACE THE BREAK-AWAY CORD EQUALIZER

1. DO NOT cut the cord holding the existing cord equalizer. You will need the full amount of cord to ensure your shade remains the same length.
2. With the shade fully raised, wrap a piece of masking tape around the cords above the equalizer to ensure they do not accidentally go into the headrail while installing the new Break-Away equalizer (tape to be removed after installation is complete).
3. Separate the new equalizer from the plastic X into 2 pieces.
4. Carefully open the old equalizer on the shade and separate the existing knot with a pin or needle. Do not cut the cord.
5. Notice on the new equalizer the top has small holes and a larger hole at the bottom. Thread one piece of cord through the top hole on the half of the new equalizer; add washer and tie a double knot in the same place on the cord where the old knot used to be, make sure that the knot is large enough not to pull through the top hole. Repeat the process with the other half of the Break-Away equalizer.
6. On the bottom pull cord of the old equalizer that holds the tassel, untie the knot at the top of the cord and thread through the bottom of the new Break-Away equalizer. Add the washer and tie in a double knot, again making sure it does not pull through.
7. Snap the 2 pieces together. Give it a few tugs to make sure that the knots are securely tied. Remove the tape from the cords. Raise and lower your shade a few times to ensure everything is working properly.

Safety in Mind